

Subject: How to adjust/verify correct functioning of the curtain sensor?

Models: NG

IMPORTANT: Disconnect the machine from the power supply. In case of replacement, it is advisable to take photos beforehand of how the item to be replaced is installed/located, in order to facilitate its commissioning.

1- Once the front part of the machine has been disassembled, we will access the inside of the machine.



2- As shown in the photo below, it is located on the right side.



3- The configuration to have is fixed, 6mm distance between the sensor and the evaporator.



4- Replace the tray, first one left coupling and then the other.
Check for proper operation.



5- Check that everything is correctly positioned.

