

**Subject: Instructions for the correct installation of the probe** (Tube in which it is placed and how it should be fastened)

**Models: NG**

**IMPORTANT:** The machine must be disconnected from the power supply. In case of replacement, it is advisable to take photos beforehand of how the item to be replaced is installed/located, in order to facilitate its commissioning.

**1-** Probe wiring should be routed to the rear of the machine. Roll it up and use flanges for its correct fastening, give several extra cms to be able to adjust it at the end of the evaporator.

As shown in the photo below.



**2-** Install the probe in the last evaporator tube as shown in the photo.

The probe must be 100% in contact with the evaporator tube.

